



GENERAL NOTES:

1. REMOVE MINIMUM 5 FEET OF SERVICE PIPE. FIELD CUT SERVICE PIPE AT 1 FOOT MAXIMUM FROM OUTSIDE EDGE OF MAIN LINE.
2. INSTALL PLUGS AT CUT SERVICE CONNECTIONS AND POUR CONCRETE COLLAR 4 INCHES EACH SIDE OF PIPE END, MINIMUM 4 INCHES THICK.
3. POUR CONCRETE AROUND CUT SERVICE CONNECTION AND CONCRETE COLLAR TO SUPPORT WEIGHT.

Kennedy/Jenks Consultants
Engineers & Scientists
 165 S Union Boulevard
 Suite 570
 Lakewood, CO 80228
 303 985 3636 TEL

SOUTH ENGLEWOOD SANITATION DISTRICT
www.southenglewood.org

SERVICE LINE
 ABANDONMENT
 DETAIL