



**SECTION A-A**

**NOTE:**  
TAPS IN STAGGERED  
CONFIGURATION AT  
10 O'CLOCK OR 2 O'CLOCK  
POSITION.

**NOTES:**

1. CONTINUE PIPE LAYING AT SAME ALIGNMENT AND GRADE THROUGH THE MANHOLE AND INSTALL AN INLINE WYE FITTING AT 10 O'CLOCK OR 2 O'CLOCK POSITION. INSTALL PLUG AT WYE FITTING OR USE THE ALTERNATE METHOD OF A PIPE STUB AND CAP.
2. CUT AND REMOVE PVC PIPE IN MANHOLE FROM SPRINGLINE TO TOP OF PIPE AND GROUT EDGES OF CUT PIPE TO INVERT AFTER BASE HAS BEEN POURED AND CONCRETE HAS SET.
3. ONLY ONE SERVICE CONNECTION IS ALLOWED PER DEAD-END MANHOLE.

**Kennedy/Jenks Consultants**  
**Engineers & Scientists**

165 S Union Boulevard  
Suite 570  
Lakewood, CO 80226  
303 985 3636 TEL

**SOUTH ENGLEWOOD SANITATION DISTRICT**

[www.southenglewood.org](http://www.southenglewood.org)

**SERVICE CONNECTIONS  
TO DEAD-END  
MANHOLES**

**DRAWING NO.: SESD-PRI-3S DATE: 8/19**